



HYPERFORM™ TECHNICAL DATA SHEET

Rev. 04-2018



**REPAIR
MATERIALS**

Typical Performance Characteristics

- Compressive Strength psi Testing Method (ASTM C39)
 - 30 minutes >1200 psi
 - 1 hour >2500 psi
 - 1 day >4000 psi
 - 28 days >7000 psi
- Bond Strength psi (ASTM C882)
 - 28 day >3000 psi
- Shrinkage Testing Method (ASTM C596)
 - 0%

RECOMMENDED FOR

- Filling large voids in manhole walls
- Reconstructing inverts
- Catch basin and concrete repair
- Pipe repair

FEATURES AND BENEFITS

- Rapid-setting
- High early and ultimate strengths
- Non-Shrinking
- No Calcium Chloride
- Ready to use, just add water
- Excellent resistance to freeze thaw

RAPID SET HIGH EARLY STRENGTH PATCHING MATERIAL

DESCRIPTION

Hyperform™ is a one component, rapid setting, high early strength patching material designed for repairing vertical and horizontal concrete and masonry structures.

PACKAGING

Hyperform is supplied in 60 lb. (27 kg.) poly-lined bags.

YIELD

One 60-lb. bag of Hyperform will yield approximately .48 cu. ft.

APPLICATION INFORMATION

Prepare surface to be patched by removing all loose concrete by using an air or electric hammer. Next, sandblast or water blast surface to clean away all contaminants, such as oil, chemicals, or dust. Then rinse with potable water to remove all remaining dirt, sand and loose debris.

Mix Hyperform with clean potable water at a rate of 1.0 gallon per 60 pound bag. If needed, Hyperform can be extended with 3/8" aggregate at a rate of 25 pounds per bag.

WARRANTY

Quadex™ warrants its products to be free of defects in material and workmanship. Within one year from purchase, if any Quadex product is proven defective, Quadex will replace said product or refund its purchase price at Quadex's sole discretion. Quadex's obligation shall be limited solely to such replacement or refund. There are no other warranties by Quadex, expressed or implied. There is no warranty if Quadex products are used contrary to Quadex's written directions.

PRECAUTIONS

Avoid eye contact or prolonged contact with skin. Wash thoroughly after use. Persons using Hyperform should wear necessary eye protection, dust mask and rubber gloves. Read all product labels and technical literature.